



POS	DESCRIPTION	QTY	POS	DESCRIPTION	QTY
01	CENTRAL BLOCK	1	21	HOUSING PUMP SCREW	20
02	SUCTION MANIFOLD	2	22	BOLT	36
03	DISCHARGE MANIFOLD	2	22A	SUCTION-DISCHARGE BOLT	8
04	PUMP HOUSING	2	23	WASHER	54
05	DIAPHRAGMS	2	24	WASHER (MANIFOLDS)	8
06	PISTON INNER	2	25	SUCTION MANIFOLD SCREW	4
07	SHAFT	1	25A	DISCHARGE MANIFOLD SCREW	4
09	O-RING BEARING	2	26	CENTRAL MANIFOLD	2
10	SHAFT BEARING	2	27	MANIFOLD ORING	4
12	SILENCER	1	31	AIR CHAMBER	2
13	AIR EXHAUST SCREW	8	32	FLANGE	2
14	AIR EXHAUST COVER	1	33	SPACER (PTFE DIAPHRAGMS)	2
15	VALVE SEAT ORING	4	34	CENTRAL BLOCK SCREW	6
17	VALVE BALL	4	35	WASHER (CENTRAL BLOCK)	6
18	BALL SEAT	4	36	CENTRAL MANIFOLD SCREW	16
19	RETAINING RING AIR VALVE	2	37	BOLT CENTRAL BLOCK	6
20	AIR CONTROL VALVE	1			