



POS	DESCRIPTION	QTY	POS	DESCRIPTION	QTY
01	CENTRAL BLOCK	1	13	AIR EXHAUST SCREW	2
02	SUCTION MANIFOLD	1	14	AIR EXHAUST COVER	2
03	DISCHARGE MANIFOLD	1	15	VALVE SEAT ORING DOWN	4
04	PUMP HOUSING	2	16	VALVE SEAT ORING UP	4
05	DIAPHRAGMS	2	17	VALVE BALL	4
06	PISTON INNER	2	18	BALL SEAT	4
06A	PISTON INNER SUPPORT	2	19	RETAINING RING AIR VALVE	2
07	SHAFT	1	20	AIR CONTROL VALVE	1
08	RETAINING RING SHAFT	2	21	HOUSING PUMP SCREW	16
09	O-RING BEARING	2	22	BOLT	24
10	SHAFT BEARING	2	23	WASHER	24
11	O-RING BEARING	2	25	SUCTION - DISCHARGE MANIFOLD SCREW	8
12	SILENCER	1	29	DRIVE AIR INLET	1
12A	SUPPORT SILENCER	1	30	PROTECTION CAP	2