



POS	DESCRIPTION	QTY	POS	DESCRIPTION	QTY
01	CENTRAL BLOCK	1	21	HOUSING PUMP SCREW	16
02	SUCTION MANIFOLD	1	22	BOLT	24
03	DISCHARGE MANIFOLD	1	23	WASHER	24
04	PUMP HOUSING	2	25	SUCTION - DISCHARGE MANIFOLD SCREW	8
05	DIAPHRAGMS	2	27	MANIFOLD CAP ORING	2
06	PISTON INNER	2	28	MANIFOLD CAP	2
07	SHAFT	1	29	DRIVE AIR INLET	1
09	O-RING BEARING	2	30	PROTECTION CAP	2
10	SHAFT BEARING	2	25	SUCTION - DISCHARGE MANIFOLD SCREW	8
11	O-RING BEARING	2	27	MANIFOLD CAP ORING	2
12	SILENCER	2	28	MANIFOLD CAP	2
12A	SUPPORT SILENCER	2	29	DRIVE AIR INLET	1
15	VALVE SEAT ORING DOWN (PTFE ONLY)	4	30	PROTECTION CAP	2
16	VALVE SEAT ORING UP (PTFE ONLY)	4	31	AIR CHAMBER	2
17	VALVE BALL	4	32	FLANGE	2
18	BALL SEAT	4	33	AIR VALVE FLANGE	2
20	AIR CONTROL VALVE	1	34	CENTRAL BLOCK SCREW	12