


# 115 PP - PVDF spare part list pump



POS	DESCRIPTION	QTY Req	POS	DESCRIPTION	QTY Req
1	CENTRAL BLOCK	1	16	VALVE SEAT ORING	6
2	MANIFOLD	2	17	VALVE BALL	4
4	HOUSING	2	18	BALL SEAT	4
5	DIAPHRAGMS	2	18A	RUNNER CAGE	4
6	PISTON INNER	2	18B	BALL SEAT ORING INSIDE	4
7	SHAFT	1	18C	RUNNER SUPPORT	2
8	RETAINING RING SHAFT	2	19	RETAING RING AIR VALVE	2
9	O-RING BEARING	2	20	AIR CONTROL UNIT	1
10	SHAFT BEARING	2	21	HOUSING SCREW	12
11	O-RING BEARING	2	22	BOLT	12
12	SILENCER	1	22A	MANIFOLD BOLT	8
13	AIR EXHUST SCREW	2	23	WASHER	28
14	AIR EXHUST COVER	1	25	MANIFOLD SCREW	8
14A	ORING SILENCER	1	29	AIR CONNECTION	1
15	VALVE SEAT ORING	2	32	SPACER	2
15A	MANIFOLD ORING	4			